

SPROG DCC

SPROG 3 DCC Decoder Programmer User Guide Supplement



Introduction.....3

Requirements.....3

Features.....3

Specification/Operating Conditions4

Installation.....5

Install SPROG 3 USB drivers.....5

The SPROG Console6

Current Limit.....6

Updates to the SPROG 3 Firmware.....7

Firmware Update Using the Bootloader.....7

Introduction

SPROG 3 is a DCC decoder programmer and command station interface for connection to the USB port of a personal computer or similar device. SPROG 3 is supported by the free JMRI software (<http://jmri.sourceforge.net/>) and <http://wiki.rocrail.net/doku.phpRocrail> also free.

SPROG 3 is also capable of operating a medium size layout, supplying up to 2.5 Amps. An even larger layout can be driven by using an external booster.

Read this document in conjunction with the SPROG llv3 User Guide available on the CD-ROM and also on the SPROG DCC website.

This Supplement covers SPROG 3 specific information only:

- **Hardware specification**
- **USB driver installation.**
- **Track output current limit**
- **Firmware updates (bootloader)**

Requirements

- JMRI from <http://jmri.sourceforge.net/> or the supplied CD-ROM
- Regulated DC Power Supply (see Table 1)
- Short length or small oval of track for programming and/or test running
- Rocrail, optional alternative to JMRI

Features

- Booster stage supplying up to 2.5 Amp to track
- Programs virtually **all** NMRA compliant DCC decoders
- No extra hardware required for programming sound decoders (e.g. QSI, Soundtraxx)
- Easy to use graphical interface with DecoderPro
- USB interface for easy connection to PC
- USB activity LED shows communication with the PC
- Power LED flashes when programming track power is live

Specification/Operating Conditions

Parameter	Minimum	Nominal	Maximum	Units
DC Input supply voltage	10V Note 1		20V	V
Vin supply current – not programming		50		mA
Vin supply current – programming		300 Note 2		mA
Vin supply current – Operating Layout			2.6 Note 3	A
Operating Temperature Range		25		°C
Output Load - programming			250 Note 2	mA
Output Load – Operating Layout			2.5 Note 3	A

Notes:

1. Minimum supply voltage depends upon the requirements of the decoder being programmed. In general it is safer to use as low a voltage as possible in case of problems with a newly installed decoder.
2. SPROG 3 will remove track power if output current exceeds 250mA as measured 100ms after applying power. Surge current during decoder power-up may be considerably greater than this.
3. To ensure correct operation of the SPROG 3 current limit, the power supply must be capable of sustaining greater than 2.5 Amp.
4. SPROG 3 is protected against reverse polarity connection of the power supply but will not work unless the polarity is correct.

Table 1 Specification/Operating Conditions


SPROG 3 is protected against reverse polarity connection of the power supply, but will not work unless the polarity is correct.

**! SPROG 3 is not protected against track and power connections being
• interchanged.**

Installation

Install SPROG 3 USB drivers

Follow the instructions in the SPROG Ilv3 User Guide but when prompted to browse to the driver directory on the CD-ROM browse to the sprog3\inf directory. For example, if your CD-ROM drive is D: browse to D:\USB\sprog3\inf as shown:



The SPROG Console

Operation of the SPROG console is as described in the SPROG II User Guide with the exception of the Current Limit setting.

Current Limit

Set the current limit for the SPROG 3 track output when using a SPROG 3 throttle, or when connected in Command Station mode. The maximum current limit is 2499mA or 2.499 Amps.

Updates to the SPROG 3 Firmware

Firmware Update Using the Bootloader

Follow the instructions in the SPROG II User Guide, selecting SPROG 3 Firmware Update rather than SPROG II Firmware Update.